

Instruction Manual

This is an easy installation glass door central lock without any drilling holes, suitable for 10-12mm glass.

1. Clean the glass with a slightly wet cloth where the lock will be installed.
2. Loosen the "side screw" before clipping the lock patch to the glass.
3. Put the lock patch to the glass and tighten the "side screw" until it is firmly fixed.
4. If you need to install the lock with a drilling hole on the glass, please use the "back screw".

